Rheostats with safety terminals

Ref. ECO3		Ref. ECO2	Ref. ECO1	Part an		ECO1	
		ETE		Ref. ECO1/2		Rh	Rheostats 640W
				TI		Ref.	
	6					ECO1-1	from 0 to 1Ω / 25A
6	6					ECO1-3.3	from 0 to 3.3 Ω / 14A
							from 0 to 4.7Ω / 12A
				0	ECO1/2	ECO1-6.8	from 0 to 6.8 Ω / 10A
					Rheostats 320W		from 0 to 10Ω / 8A
			ECO2	Ref.		ECO1-15	from 0 to 15Ω / 6.5A
		Rhe	Rheostats 1300W			ECO1-25	from 0 to 25Ω / 5A
					from 0 to 1Ω / 18A	ECO1-33	from 0 to 33Ω / 4.4A
		Ref.		ECO1/2-3.3	from 0 to 3.3Ω / 10A	ECO1-50	from 0 to 50Ω / 3.6A
		ECO2-0.5	from 0 to 0.5Ω / 50A	ECO1/2-10	from 0 to 10Ω / 5.7A	ECO1-68	from 0 to 68Ω / 3A
ECO3		ECO2-1.6	from 0 to 1.6Ω / 28A	ECO1/2-15	from 0 to 15Ω / 4.5A	ECO1-100	from 0 to 100Ω / 2.5A
Rheostats 1900W		ECO2-5	from 0 to 5Ω / 16A	ECO1/2-22	from 0 to 22Ω / 3.8A	ECO1-150	from 0 to 150Ω / 2A
		ECO2-11.5	from 0 to 11.5Ω / 10A	ECO1/2-33	from 0 to 33Ω / 3.1A	ECO1-210	from 0 to 210Ω / 1.7A
Ref.		ECO2-16.5	from 0 to 16.5Ω / 8.7A	ECO1/2-47	from 0 to 47Ω / 2.6A	ECO1-330	from 0 to 330Ω / 1.4A
ECO3-0.33	from 0 to 0.33Ω / 76A	ECO2-23.4	from 0 to 23.4Ω / 7.2A	ECO1/2-68	from 0 to 68Ω / 2.2A	ECO1-470	from 0 to 470Ω / 1.2A
ECO3-1.1	from 0 to 1.1Ω / 42A	ECO2-33	from 0 to 33Ω / 6A	ECO1/2-100	from 0 to 100Ω / 1.8A	ECO1-650	from 0 to 650Ω / 1A
ECO3-3.3	from 0 to 3.3Ω / 24A	ECO2-50	from 0 to 50Ω / 5A	ECO1/2-150	from 0 to 150Ω / 1.5A	ECO1-1000	from 0 to 1000Ω / 0.8A
ECO3-11	from 0 to 11Ω / 13A	ECO2-106	from 0 to 106Ω / 3.3A	ECO1/2-220	from 0 to 220Ω / 1.2A	ECO1-1500	from 0 to 1500Ω / 0.65A
ECO3-33	from 0 to 33Ω / 7.6A	ECO2-165	from 0 to 165Ω / 2.8A	ECO1/2-330	from 0 to 330Ω / 1A	ECO1-2200	from 0 to 2200Ω / 0.54A
ECO3-110	from 0 to 110Ω / 4.2A	ECO2-325	from 0 to 325Ω / 1.9A	ECO1/2-470	from 0 to 470Ω / 0.8A	ECO1-3300	from 0 to 3300Ω / 0.44A
ECO3-333	from 0 to 333Ω / $2.4A$	ECO2-500	from 0 to 500Ω / 1.6A	ECO1/2-680	from 0 to 680Ω / 0.7A	ECO1-4700	from 0 to 4700Ω / 0.37A

ECO3-3300 from 0 to 3300Ω / 0.76A Dim. : 470 x 248 x 163mm / 8.3kg

ECO3-1100 from 0 to 1100Ω / 1.4A

Dim. : 470 x 164 x 163mm / 5.5kg

ECO2-1650 from 0 to 1650Ω / 0.9A

ECO2-5000 from 0 to $5k\Omega$ / 0.5A

Dim. : 270 x 92 x 163mm / 1.9kg

ECO1/2-1000 from 0 to $1000\Omega / 0.6A$

ECO1/2-3300 from 0 to 3300Ω / 0.3A

Dim. : 470 x 92 x 163mm / 3kg

ECO1-6800 from 0 to 6800Ω / 0.31A

ECO1-10000 from 0 to $10 M\Omega$ / 0.25A

3-Phase Rheostats

3 resistors inside



- There are 3 resistors inside this rheostat all insulated from each other
- One button allows the varying of the resistance of all of them simultaneously.
- Connected in star or delta, the rheostats make for a balanced 3-phase load.

ECOTRI							
Rheostats 1900W							
Ref. *	VALUES						
ECOTRI-1	from 0 to 3 x 1Ω / 3 x 25A						
ECOTRI-3.3	from 0 to 3 x 3.3Ω / 3 x 14A						
ECOTRI-10	from 0 to 3 x 10Ω / 3 x 8A						
ECOTRI-33	from 0 to 3 x 33Ω / 3 x 4.4A						
ECOTRI-100	from 0 to 3 x 100Ω / 3 x 2.5A						
ECOTRI-330	from 0 to 3 x 330Ω / 3 x 1.4A						
ECOTRI-1k	from 0 to 3 x 1kΩ / 3 x 0.8A						
ECOTRI-3.3k	from 0 to 3 x 3.3k Ω / 3 x 0.44A						
ECOTRI-10k	from 0 to 3 x 10kΩ / 3 x 0.25A						
Dim. : 470 x 248 x 163mm / 8.3kg							

9 safety terminals + 1 earth terminal

OPTION	- CRANK

